



Note 1: To dial lamp circuit as shown for individual or bridged.
Note 2: Dotted lines indicate connections for manual service. The dial remains on the set.

Fig. 3 — 701B Telephone Set with E1A or E2A Ringer

**TABLE B
 LINE AND RINGER CONNECTIONS WITH E1A OR E2A RINGER**

Wire or Lead	Individual or Bridged	Ring Party	Tip Party	Tip Party with Ident Grd	
				1000Ω	2650Ω
Line at Ringer	Ring	R	5	6	6
	Tip	G	6	5	5
	Grd	Y	2	2	2
Ringer		R	7	7	1
		S-R	1	1	2
		BK	6	2	1
		S	1	1	7
Capacitor in Ringer		W	7	7	7
		Y	5	5	3
Transformer Leads at Ringer		1	2	2	2
		2	4	4	4
Mounting Cord at Ringer		R	5	5	5
		G	6	6	6
		Y	2	2	2
		BL	4	4	1
		W	3	3	3
		BK	4	4	4
Mounting Cord at Set*		R	L2	L2	L2
		G	L1	L1	L1
		Y	3	3	3
		BL	4	4	B
		W	D	D	D
		BK	4	4	4

* Wired at factory for individual or bridged, ring- and tip-party service.

